

Operation Principle and Wiring SimpleStarter SST130i Single phase 50A/30A, resp. 140A/30A - 230V~ 50Hz Soft starter

